#### **HDMI Dual Monitor KVM Switch**

#### # HKS0802A1U

HDMI Dual Monitor KVM Switch can easily integrate cross-platform computer devices. Our Dual Monitor KVM Switch can help you add more inputs to your TV or AV receiver if you have too many devices to manage. Each input device requires 2 HDMI inputs to display to 2 monitors. Support 2 display mode, you can choose any connected PC to duplicate or extend to 2 monitors, or switch any PC to display on any monitor at will. Support DCCI, you can extend the connected PCs to up to 4 monitors using 2 of this KVM Switch. Supports using USB hubs and USB keyboard and mouse. You can connect a printer, USB drive, bar code scanner or other USB 2.0 devices to this KVM. This product also supports several other switching modes. You can switch input ports with front panel button, IR signals and keyboard hot keys.

#### **Features**


- Using only 1 set of keyboard, mouse and 2 monitors to control 4 computers
- Support Unix/Windows/Debian/Ubuntu/Fedora/Mac OS X/Raspbian/Ubuntu for Raspberry Pi and other Linux basic systems
- Support resolution up to 3840\*2160@60HZ
- Support hot plug, disconnect or connect devices to the KVM at any time without turning off PC
- With EDID emulators in each input port, keep PCs always having correct information
- Support front panel button, keyboard hotkeys, IR remote control and RS232 to control KVM
- Available to use keyboard and mouse without any delay after switching input sources
- With extra USB 2.0 port, it is possible to connect barcode scanner, USB hard device or other USB devices
- Support keyboard and mouse pass through mode to improve KVM compatibility
- Support DCCI

### **Packing list**

- 1 \* Dual Monitor HDMI KVM Switch
- 1 \* IR remote control
- 1 \* IR Receiver cable
- 1 \* DC 12V power adapter
- 1 \* 3 Pins Connector(For RS232)
- 2 \* Rack-ears
- 1 \* AUX Cable
- 1 \* User manual

1

## **Panel Descriptions**



ID	Name	Description
1	DC 12V input	DC 12V power supply
2	RS232 port	Connect this port to any control termination, then it is able to select the input sources by sending RS232 commands
3	Ext.IR	For extended IR receiver cable input
4	L/R audio output	Analog audio output, connect to speaker
5	Standard USB 2.0 port	Connect to USB 2.0 devices, printers, USB drives
6	DCCI port	Used for product cascading to realize simultaneous display of 4 monitors
7	Keyboard and mouse input	Connect to keyboard and mouse
8	HDMI output ports	Connect to HDMI displays
9	PC 4 Input	HDMI input A/B:Connect to the two outputs of the same computer USB:Connect to computer by USB Type A to Type B cable
10	PC 3 Input	HDMI input A/B:Connect to the two outputs of the same computer USB:Connect to computer by USB Type A to Type B cable
11	PC 2 Input	HDMI input A/B:Connect to the two outputs


2



of the same computer USB:Connect to computer by USB Type A to Type B cable  HDMI input A/B:Connect to the two outputs of the same computer USB:Connect to computer by USB Type A to Type B cable  [MIN]: Press [MIN] to loop between 0~59 minutes  [SEC]: Press [SEC] to loop between 0~59 seconds [Set]: After setting minutes and seconds, press button [Set] to enter final scan time interval setting  14  LED display Display current selected input port  Red: Turn off auto scanning mode Green: Turn on auto scanning mode Green: Turn on auto scanning mode Input 1~4 [Output A]: Reyboard and mouse focus on the desktop of output A in the display mode 2 [Output B]: Keyboard and mouse focus on the desktop of output B in the display mode 2 [Output A]+[1~4]: After pressing [Output A], then press [1~4] to switch input sources of output A [Output B]+[1~4]: After pressing [Output B], then press [1~4] to switch input sources of output B [Close]: Press this button to turn on or off the LED display and monitor [Scan]: Press this button to start or stop automatically scanning between input1 to input8. The interval time can be set by [Set], [MIN], [SEC] as described above  18 Power switch Trun on or turn off power supply			
HDMI input A/B:Connect to the two outputs of the same computer USB:Connect to computer by USB Type A to Type B cable  [MIN]: Press [MIN] to loop between 0~59 minutes  [SEC]: Press [SEC] to loop between 0~59 seconds  [Set]: After setting minutes and seconds, press button [Set] to enter final scan time interval setting  14   LED display			<b>USB:</b> Connect to computer by USB Type A to
Auto scan time interval settings  Auto scan time interval settings  [SEC]: Press [SEC] to loop between 0~59 seconds [Set]: After setting minutes and seconds, press button [Set] to enter final scan time interval setting  Display current selected input port  Red: Turn off auto scanning mode Green: Turn on auto scanning mode  Receive IR remote signal  [1~4]: Press button[1]~[4] to directly select input 1~4 [Output A]: Keyboard and mouse focus on the desktop of output A in the display mode 2 [Output B]: Keyboard and mouse focus on the desktop of output B in the display mode 2 [Output A]+[1~4]: After pressing [Output A], then press [1~4] to switch input sources of output A [Output B]+[1~4]: After pressing [Output B], then press [1~4] to switch input sources of output B [Close]: Press this button to turn on or off the LED display and monitor [Scan]: Press this button to start or stop automatically scanning between input1 to input8. The interval time can be set by [Set], [MIN], [SEC] as described above	12	PC 1 Input	HDMI input A/B:Connect to the two outputs of the same computer USB:Connect to computer by USB Type A to
Red: Turn off auto scanning mode Green: Turn on auto scanning mode Receive IR remote signal  [1~4]: Press button[1]~[4] to directly select input 1~4 [Output A]: Keyboard and mouse focus on the desktop of output A in the display mode 2 [Output B]: Keyboard and mouse focus on the desktop of output B in the display mode 2 [Output A]+[1~4]: After pressing [Output A], then press [1~4] to switch input sources of output A  [Output B]+[1~4]: After pressing [Output B], then press [1~4] to switch input sources of output B [Close]: Press this button to turn on or off the LED display and monitor [Scan]: Press this button to start or stop automatically scanning between input1 to input8. The interval time can be set by [Set], [MIN], [SEC] as described above	13		minutes [SEC]: Press [SEC] to loop between 0~59 seconds [Set]: After setting minutes and seconds, press button [Set] to enter final scan time
Green: Turn on auto scanning mode  Receive IR remote signal  [1~4]: Press button[1]~[4] to directly select input 1~4  [Output A]: Keyboard and mouse focus on the desktop of output A in the display mode 2  [Output B]: Keyboard and mouse focus on the desktop of output B in the display mode 2  [Output A]+[1~4]: After pressing [Output A], then press [1~4] to switch input sources of output A  [Output B]+[1~4]: After pressing [Output B], then press [1~4] to switch input sources of output B  [Close]: Press this button to turn on or off the LED display and monitor  [Scan]: Press this button to start or stop automatically scanning between input1 to input8. The interval time can be set by [Set], [MIN], [SEC] as described above	14	LED display	Display current selected input port
[1~4]: Press button[1]~[4] to directly select input 1~4  [Output A]: Keyboard and mouse focus on the desktop of output A in the display mode 2  [Output B]: Keyboard and mouse focus on the desktop of output B in the display mode 2  [Output A]+[1~4]: After pressing [Output A], then press [1~4] to switch input sources of output A  [Output B]+[1~4]: After pressing [Output B], then press [1~4] to switch input sources of output B  [Close]: Press this button to turn on or off the LED display and monitor  [Scan]: Press this button to start or stop automatically scanning between input1 to input8. The interval time can be set by [Set], [MIN], [SEC] as described above	15	Status LED	_
input 1~4  [Output A]: Keyboard and mouse focus on the desktop of output A in the display mode 2  [Output B]: Keyboard and mouse focus on the desktop of output B in the display mode 2  [Output A]+[1~4]: After pressing [Output A], then press [1~4] to switch input sources of output A  [Output B]+[1~4]: After pressing [Output B], then press [1~4] to switch input sources of output B  [Close]: Press this button to turn on or off the LED display and monitor  [Scan]: Press this button to start or stop automatically scanning between input1 to input8. The interval time can be set by [Set], [MIN], [SEC] as described above	16	IR receiver	Receive IR remote signal
	17	Keypad	input 1~4 [Output A]: Keyboard and mouse focus on the desktop of output A in the display mode 2 [Output B]: Keyboard and mouse focus on the desktop of output B in the display mode 2 [Output A]+[1~4]: After pressing [Output A], then press [1~4] to switch input sources of output A [Output B]+[1~4]: After pressing [Output B], then press [1~4] to switch input sources of output B [Close]: Press this button to turn on or off the LED display and monitor [Scan]: Press this button to start or stop automatically scanning between input1 to input8. The interval time can be set by [Set],
	18	Power switch	



## **Connection Diagram**




4



### **DCCI Connection Diagram**

**Note:** The slave only connects to monitors and computers.

Computers need to connect 4 HDMI cables simultaneously.



5

# **Specification**

HKS0802A1U	HDMI Dual Monitor KVM Switch			
Functionality:				
Auto Scan	Yes			
	Front panel buttons	Yes		
Port selection	Keyboard hotkeys	Yes		
FOR SELECTION	IR remote control	Yes		
	Console commands	RS232		
Technical:				
Max. Resolution	. Resolution 3840x2160@60Hz			
Auto to get EDID	Yes			
Data rate	e 18 Gbps			
OSD	O No			
	Unix/Windows/Debian /Ubuntu /Fedora /Mac OS X/			
Supported OS	Raspbian /Ubuntu for Raspberry Pi and other Linux based			
	systems			
	Video /Audio	8 * HDMI Type A		
Input ports	USB 2.0 Hub ports	3 * USB Type A		
	USB Data	4 * USB Type B		
	Video /Audio	2 * HDMI Type A		
	Keyboard/Mouse	2 * USB Type A		
	emulation			
Output ports	L/R audio output	1*AUX		
	DCCI output	1*AUX		
	Ext.IR	1 * AUX		
	RS232	3 Pins jack		
ESD protection	Human body m	nodel - ±8kV (Air-gap discharge)		
Mechanical:				
Chasing material	Metal			
Product	Dimension	350 (L) x 149 (W) x 44.5 (H) mm		
	Weight	1277g		
Item	Dimension	397 (L) x 197(W) x 107 (H) mm		
	Weight	2409g		
Cartan	Dimension	505 (L) x 280 (W) x 395 (H) mm		
Carton	Quantity	4pcs		
	Total Weight	10.386kg		